


Flex Lance Safety Grip



The **FLEX LANCE SAFETY GRIP** is designed to minimize the risk of injury to flex lance operators caused by a live nozzle exiting the tube unexpectedly.

The comfortably contoured handle makes it easy to hold the **SAFETY GRIP** against the tube sheet, allowing retraction of an active nozzle into a stainless steel sleeve where the force of the jets is dissipated.


The **FLEX LANCE SAFETY GRIP** is simple to install and is quickly adapted to handle various lance sizes by selecting the appropriately sized **LANCE STOP**.

Note: Three **LANCE STOPS** for the most common 4mm, 5mm and 6mm diameter hoses are provided with each **SAFETY GRIP**. Additional sizes are available separately.

Installation of LANCE STOPS: Simply unscrew the **DIFFUSER** from the **SAFETY GRIP HANDLE**, which will allow the **LANCE STOP** to be removed. Insert the new lance into the back of the **SAFETY GRIP HANDLE**. Select the correct size **LANCE STOP** for the lance to be used and place it onto the lance behind the nozzle end fitting. Insert the nozzle through the **DIFFUSER** and tighten the assembly into the **HANDLE**. (Note: the larger diameter end of the Lance Stop must be next to the end fitting.)

Part #	Flex Lance Safety Grip
35-009-000	COMPLETE ASSEMBLY: Small Flex Lance Safety Grip*
35-009-001	HANDLE: Small Flex Lance Safety Grip
35-009-007	DIFFUSER: Small Flex Lance Safety Grip

* Includes 3 Standard Lance Stops; 4mm, 5mm & 6mm.



Part #	Flex Lance Grip Stops
35-009-002	.323" (3mm) Flex Lance Safety Grip Stop
35-009-003	.390" (4mm) Flex Lance Safety Grip Stop
35-009-004	.442" (5mm) Flex Lance Safety Grip Stop
35-009-005	.510" (6mm) Flex Lance Safety Grip Stop
35-009-006	.725" (7mm) Flex Lance Safety Grip Stop

ADVANCED PRESSURE SYSTEMS

701 S. Persimmon, Suite 85 - Tomball, Texas 77375

Toll Free in North America: 1 (877) 290-4277

Phone: (281) 290-9950 Fax: (281) 290-9952

E-mail orders: sales@advancedpressuresystems.com